

# qPCR 8連排暨4連排機型適配表

	*Tray/Retainer No.	MB-Q100	MB-Q100C	MB-Q100W	MB-Q200	MB-Q200W	MB-QR4
<b>ABI</b>							
7000	4350105				●		
7300/7500	4367033				●		
7500 Fast 96-Wells Block (0.1mL model)	A29252	●					
Step One	4375282	●					
Step One Plus	4379983	●					
ViiA7 Fast 96-Wells Block (0.1mL model)	4379983	●					
ViiA7 96-Wells Block (0.2mL model)	4381850				●		
QuantStudio Fast 96-Wells Block (0.1mL model) (QuantStudio3/5/6/6 Pro/7/7 Pro/12K)	4379983	●					
QuantStudio 96-Wells Block (0.2mL model) (QuantStudio1/3/5/6/6 Pro/7/7 Pro/12K)	4381850				●		
3500,3500xL 96-Wells Block (0.1mL model)	Retainer(4410232) Septa(4410701)	●					
3500,3500xL 96-Wells Block (0.2mL model)	Retainer(4410230) Septa(4410701)				●		
SeqStudio Genetic Analyzer	Retainer(403081) Septa(A36543)				●		
<b>Roche</b>							
LightCycler 480I & 480II 96-Wells Block	Adapter(06612598001)			●			
LightCycler 96				●			
LightCycler Nano			●				
<b>Bio-Rad</b>							
CFX96 & CFX96 Connect		●		●			
CFX Opus 96		●		●			
<b>Analytik Jena</b>							
qTOWER <sup>3</sup> G & qTOWER <sup>3</sup> G touch				●		●	
<b>Qiagen</b>							
Rotor Gene Q							●
Qiagen_QIAquant				●		●	
<b>Agilent-Stratagene</b>							
AriaMx		●					
Mx3005PM, Mx3000P					●		

- 當使用8連排於ABI 機器中，請注意使用適當的支撐架(請見圖表左方支撐架型號)，避免管身變形。
- 當使用8連排於ABI step one (plus)機器中，建議使用2條八連排分別放置A3-A10及H3-H10的位置，避免管身變形。相關參考資料請至<https://goo.gl/eCmNvK>